



**Plan ahead, thanks to the delay-start function**

With this delay-start function, you can plan ahead. So you get clean dishes when you want them, without switching the dishwasher on straight away.

**Product Benefits & Features**

**Ready when you are**

Make the most of the time you have available with the delay start function in our dishwashers. Preset a start time, within a 3 hours time span after you have loaded your dishes, and enjoy the convenience of having clean dishes when you want them.

- Sensorlogic Dishwasher
- LED display
- Warm water 60°C
- 4 programmes, 3 temperatures
- Dishwasher programmes: Eco, Intensive 70°, Normal 65°, Rinse & Hold
- Options:None
- Delay start option: 3h
- Inverter motor
- Height adjustable upper basket
- Upper basket with
- Cutlery basket
- Lower basket with Fixed plate racks
- AQUA-CONTROL
- Installation in height
- Anti fingerprint stainless steel finishing
- Panel with symbols
- Indications for salt and rinse aid

**Rinse off your dishes when the dishwasher is not yet full**

When your dishwasher is only half full, you may want to wait before you run a full cycle. The Rinse & Hold program quickly rinses partial loads of dirty dishes, minimising unpleasant smells and keeping bacteria at bay.

**Product Specification**

Product Number Code	911 529 188	Height total	818
EPRELRegCodeE20	294622	Width mm	596
Bar code	7332543520978	Depth mm	575
EnergyClassE20	F	Built in depth mm	550
EnergyCons100CycleE20	104	Built in height (min), mm	820
RatedCapacityE20	13	Built in width mm	600
WaterConsE20	9.9	Weight gross cleaner and accessories with packaging	39.92
ProgrammeDurE20	3:47	Weight net cleaner and accessories no packaging	38.4
NoiseClassE20	C	Package height	864
NoisedBAE20	49	Package width	635
OffModePwE20	0.5	Package depth	680
StandByPwE20	0.5	Weight package Paper/Carton	8.6
Installation in height	Yes	Weight package Wood	0
Installation	I	Weight package PE	200
Inlet hose type of	Aqua control	Weight package PP	0
Anti-flood device	Floating switch	Weight package Polystyrene (EPS/EPP)	902
Water supply	Cold or hot	Country of origin	PL
DelayStartE20	4		
Dishwasher programs	Eco, Intensive 70°, Normal 65°, Rinse & Hold		
Panel colour	Stainless steel		
Required fuse (A)	10		
Connected load (W)	1950		
Voltage	220-240		
Cord length external	1.5		

PSGBDW200DE00004

