

FSE32407Z



Natural drying with fresh air. For perfectly dry dishes

The 3000 AirDry Dishwasher maximises drying using natural airflow. The door automatically opens 10 cm in the final stage of the cycle, drying dishes naturally and effectively. Dishes dry 3x better than closed-door systems.

Product Benefits & Features



Open the door to dry dishes

AirDry delivers up to 3x better drying performance when compared to closed-door systems. The door automatically opens at the end of the drying phase and air is circulated inside the machine. Dishes emerge perfectly dry. Every time.

Water reaches every corner. With the Dual Spray Arms

Ensure maximum water coverage with two spray arms. The rotating sprinklers send water jets into every corner of both the lower and upper basket, for dishwashing results you can rely on.

QuickLift—adjust the basket height even when fully loaded

Indulge in the efficient amenities provided by the QuickLift basket. Regardless if you have a full load with bulky items, you can effortlessly adjust the height so you can easily fit dishes and kitchen tools of different shapes and sizes.

- · Water sensor detects the level of dirt and adjusts water consumption
- · LED Display with QuickSelect
- · Touch control for programs and functions selection
- AutoOff
- Warm water 60°C
- 5 programmes, 3 temperatures
- Dishwasher programmes: 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes
- Options:XtraPower
- Dual Spray Arm
- · Delay start option: 3h
- Buzzer
- Inverter motor
- Sliding door 645-776 mm
- · Height adjustable upper basket, even when fully loaded
- Upper basket with Plastic coloured handle
- Cutlery basket
- · Lower basket with 2 foldable plate racks, Plastic coloured handle
- AQUA-CONTROL
- Installation in height
- Panel with symbols
- · Indications for salt and rinse aid

Fast and efficient performance

This dishwasher gives you perfect performance - fast, thanks to its special half-hour program.

Efficiently clean. In every cycle

The special sensor in our AutoSense program detects how much cleaning your dishes need. Using just the right amount of water, energy and time needed to do the job properly. Meaning dishes are cleaned in the most eco-friendly way possible.



FSE32407Z

Product Specification	
Product Number Code	911 075 043
EPRELRegCodeE20	294453
Bar code	7332543735570
EnergyClassE20	E
EnergyCons100CycleE20	70
RatedCapacityE20	9
WaterConsE20	9.9
ProgrammeDurE20	4:00
NoiseClassE20	С
NoisedBAE20	46
OffModePwE20	0.5
StandByPwE20	0.5
Installation in height	Yes
Installation	FI
Inlet hose type of	Aqua control
Anti-flood device	Floating switch
Water supply	Cold or hot
DelayStartE20	4
Dishwasher programs	90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes
Panel colour	Black
Required fuse (A)	10
Connected load (W)	1950
Voltage	220-240
Cord length external	1.5

Height total	818
Width mm	446
Depth mm	550
Built in depth mm	550
Built in height (min), mm	820
Built in width mm	450
Weight gross cleaner and accessories with packaging	33.03
Weight net cleaner and accessories no packaging	31.55
Package heigth	870
Package width	490
Package depth	685
Weight package Paper/Carton	3
Weight package Wood	162
Weight package PE	190
Weight package PP	0
Weight package Polystyrene (EPS/EPP)	880
Country of origin	PL



